

What LiPo do I have?



1 Cell

Min. voltage = 3.0V
Nom. voltage = 3.7V
Max. voltage = 4.2V



4 Cell

Min. voltage = 12.0V
Nom. voltage = 14.8V
Max. voltage = 16.8V




6 Cell


Min. voltage = 18.0V
Nom. voltage = 22.2V
Max. voltage = 25.2V

Do NOT let the LiPo get under the minimum voltage!
Check the LiPo voltage before driving
Intense driving? Check LiPo voltage every 15 minutes


How to charge a LiPo



1. Connect LiPo



2. Choose "LiPo"



3. Balance Charge
End voltage = 4.2
Charge Current 2A
Press START

Never leave a charging LiPo unattended!